



DATE: February 24, 2016

TOPIC: Installation Tip

VEHICLE: 2015-16 Chevy Tahoe / GMC Yukon

When installing interiors for these vehicles, the ABS plastics from the front backs and middle cushions of the factory cloth covers must be re-used. To assist you in this effort, the Katzkin patterns include a pocket for this factory plastic to be re-inserted into the cover. We also recommend trimming the selvage off from the seams which will provide a nice, smooth edge along the radius of the curve.



PATTERN SCHEMATIC

Ramon Avelar
Date Created: 08/11/2015
Revision: 1 - 08/11/2015

