



SEAT HEATER INSTALLATION BULLETIN (Res Wire)

For proper operation and optimal thermal performance, heater pads must be installed in the proper location for each pad. Each is labeled to indicate its proper location - CU for cushion, and BACK for lean back. Reversing these locations could result in failure of the heat sensor and/or overheating of the unit. Remember: the heat sensor is ALWAYS placed in the cushion.

